

7200 COMM - No START character - Hyper Terminal:

Uses Y-Model Protocol

YFF initiates the transfer

Terminal sends connection packets

Load Program on PC received packets and then sends program

No start character may mean the program does not receive the packet

Could be hardware issue

On PC – go to Hyper terminal to open connection on terminal to see if can receive characters

Connect to COM1 then use YFF on Terminal

Then on Hyper Terminal, should see characters if connection ok

Ref: No. 4 in Troubleshooting Serial Comms article

http://www.z-space.com/ITScriptNet/faq/itscriptnet_communications.htm